**010-06-01**

# Altimeter setting procedures: key figures

3 figures in 3 groups. Read the cue, say the figure, then check. Each group ends with a recap. Rules change: check the regulation in force.

PPL Knowledge · © rpvfalmeida · CC BY-NC-ND 4.0 Educational content. It does not replace ATO instruction.

## Subscale setting for flight levels, the standard setting

# 1013.2 hPa

Set on the subscale, the altimeter reads flight levels

# Datums and settings: recap

| CUE | FIGURE | DETAIL |
| --- | --- | --- |
| Subscale setting for flight levels, the standard setting | **1013.2 hPa** | Set on the subscale, the altimeter reads flight levels |

> **Standard setting 1013.2 hPa: flight levels for every aircraft.**

## VMC band boundary when the transition altitude is lower than 10 000 ft (3 050 m) AMSL

# FL 100

Replaces 10 000 ft (3 050 m) AMSL when the transition altitude is lower than that

# Boundaries linked to the TA: recap

| CUE | FIGURE | DETAIL |
|---|---|---|
| VMC band boundary when the transition altitude is lower than 10 000 ft (3 050 m) AMSL | FL 100 | Replaces 10 000 ft (3 050 m) AMSL when the transition altitude is lower than that |

**Low TA: FL 100 replaces 10 000 ft.**

## Altimeter setting that is said as words, not digits

# 1 000 hPa

Said ONE THOUSAND; every other setting is said digit by digit

# Phraseology: recap

| CUE | FIGURE | DETAIL |
|---|---|---|
| Altimeter setting that is said as words, not digits | **1 000 hPa** | Said ONE THOUSAND; every other setting is said digit by digit |

**1 000 is ONE THOUSAND; every other setting is digit by digit.**